


## Konfigurationsübersicht / Configuration Shortcut

### DAM 4000 Basic / DAM Basic IR

Passend zu / fitting to 112-400-04-000-00, 112-400-01-000-00

### Menü Zentraleinheit DAM 4000 Basic:



Version 1.0

Technische & optische Änderungen vorbehalten / Modifications reserved


22.09.2011

## Konfigurationsübersicht / Configuration Shortcut

### DAM 4000 Basic / DAM Basic IR

Passend zu / fitting to 112-400-04-000-00, 112-400-01-000-00

### Menu Central Unit DAM 4000 Basic:



Version 1.0

Technische & optische Änderungen vorbehalten / Modifications reserved


22.09.2011

## Konfigurationsübersicht / Configuration Shortcut

### DAM 4000 Basic / DAM Basic IR

Passend zu / fitting to 112-400-04-000-00, 112-400-01-000-00

### Menü Bedieneinheit DAM Basic IR:



Version 1.0

Technische & optische Änderungen vorbehalten / Modifications reserved


22.09.2011

## Konfigurationsübersicht / Configuration Shortcut

### DAM 4000 Basic / DAM Basic IR

Passend zu / fitting to 112-400-04-000-00, 112-400-01-000-00

#### Menu Control Unit DAM Basic IR:



Version 1.0

Technische & optische Änderungen vorbehalten / Modifications reserved

22.09.2011